




1




2




2





3




4



3



5



4


2x 6031056	5x 6028812	1x 4211128	1x 4212529	1x 6074686	1x 4624369	1x 6074884	1x 6022010
1x 4211413	1x 4654580	7x 4504378	9x 4211098	4x 4619509	1x 379528	2x 4211100	1x 4211360
1x 4211396	4x 6044729	1x 4211096	8x 4216479	4x 4619514	2x 6040336	2x 4210875	1x 6083029
2x 4211356	1x 6044729	5x 4210631	2x 4615728	2x 6070777	1x 4622575	1x 4620760	1x 4211002
1x 4560183	1x 4211370	2x 4211119	3x 4599686	1x 4619512	1x 4619507	2x 4509897	
1x 4211807	1x 4211550	2x 4211065	1x 6079159	2x 4619516	3x 4625027	1x 4211805	
1x 4211404	1x 4211807	2x 4210726	1x 6073222	1x 4619507	1x 4502193	1x 6003298	
4x 4211385	1x 6071286	1x 4543086	1x 6017024	1x 6073451			
2x 4632575	2x 4211105	2x 4210633	1x 6034812				
2x 4594238	7x 4211054	2x 4509884					

Customer Service
Kundenservice
Service Consommateurs
Servicio Al Consumidor
LEGO.com/service or dial

: 00800 5346 5555
 : 1-800-422-5346



41030



41031




41034



41058


6

2x 1x 1x



7

1x 1x




5





68

8




6





9




7




58



65



10



8



66


56



63



11



9




57




64




12




10




13




11




7



61



14



12


55




62




5



59




15



13





6




60




16



14




17



15




54



57



18



16



1




2


58



3



4



- 1x
- 2x
- 1x
- 1x

52




55



- 2x
- 1x


19



17

- 1x


53



56

- 3x


20



18

- 1x
- 1x
- 2x

21



19

- 1x
- 1x

50



53



- 1x
- 1x
- 1x

1



- 1x

2



20

- 1x
- 1x

51



54




48



51



3



4



21



49



52



5



22




6




7



23




46



49



8



24



47



50




44



47

22



25



45



48



23



26



24



27



42



45



25



28



43




46



40



43



26



29



41



44



27



30



28



31



38




41




29




32



39



42



36




39




30




33



37




40




31



34



32




35



34



37





33



36



35



38